



DAIKIN 2-DAY TRAINING DAY 2

1-888-823-4357



NATE ACCREDITATION

8 HOURS per day TOWARD NATE recertification




Multi Port Priority: How Does it Work?

Option #1 Floating Priority (First Come First Serve)



THE MULTI PORT CONCEPT: FLOATING PRIORITY Everybody Cooling

Living Room is Master Unit Because First Unit On




DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

THE MULTI PORT CONCEPT: FLOATING PRIORITY

Guest Rooms Calls for Heat

Stand By Until Living Room Master Unit is Shut OFF




DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

THE MULTI PORT CONCEPT: FIRST COME FIRST SERVE

Once original master is OFF, guest bedroom becomes new master. All other units are subject to the same mode again.



DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

Multi Port Priority:

How Does it Work?


Option #2 Dedicated Priority



SETTING PRIORITY


Multi 2, 3, & 4-Port Priority Set Up

- You should choose a Priority Unit during install.
- For 2-Port Multi. Inside outdoor unit on PCB slide A or B dip switch over opposite others.
- For a 3 or 4-Port Multi. Inside outdoor unit on PCB slide A, B, C or D dip switch over opposite others.
- This must be done with power off



THE MULTI PORT CONCEPT: DEDICATED PRIORITY Guest Rooms Calls for **Heat**

If Master Unit is selected via dipswitch at outdoor unit, no other indoor unit can change mode.



DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

SYSTEM START-UP AND COMMISSIONING



SYSTEM START UP CHECKLIST

- Indoor and outdoor units are installed securely & are level.
- Pressure test system to 550 PSIG for 24 hours.
- Perform triple evacuation on system.
 - To 500 microns breaking with dry Nitrogen each time
- Calculate liquid line length and corresponding required additional refrigerant charge.
 - Weigh in additional charge to liquid line.
- Open service valves.
- Check supply voltage (L1 to L2).
 - Must read between 187 and 253 volts.



SYSTEM START UP CHECKLIST

- Ensure all drain pipe is properly connected.
- Ensure all filters are in place.
- Ensure all refrigerant piping is properly insulated.
 - Insulate each line independently.
- Power system on for 6 hours before startup.
 - Single Split – Turn on the indoor unit using the remote control and test each mode of operation
 - Multi Split – Turn on each indoor unit individually using the remote control and test each mode of operation.
 - Priority Set-up

NOTE: All modes of operation may not be available depending on the outside ambient conditions, see the sequence of operation for more information.



**If system does not operate properly,
proceed to Troubleshooting**





Ductless Startup Checklist

Equipment Requirements to Perform Proper Maintenance:

- 2-Stage Vacuum Pump
- Micron Gauge (Digital or Analog)
- Multimeter
- Schrader Valve Removal Tools
- Megger Meter
- Hoses
- Flaring Tools
- Common Hand Tools
- Manifold Gauges
- Voltmeter
- Ammeter
- Temperature Probe



Micron gauge



Schrader Valve removal tool

Vacuum Pump



Megger meter



Bluetooth pipe clamps



Temperature probe



Service Checker



Multimeter



Pressure gauges



Wireless and wired D checker



Torque wrenches

Large Tool Bag



Daikin offers a small and large Tool Bag:

These items can also be purchased individually from your local distributor.

3. The document does not supersede other technical documentation such as the installation, operation, and/or service manuals provided by Daikin North America, Ltd. or its local companies. Daikin products are subject to continuous improvements. Daikin assumes no right to modify product design, specifications, and information without notice and without liability, any damages.

BACK



Ductless Startup Checklist

Customer/Technician Information

Date	Time Arrived	Time Departed	
Customer Name			
Customer Number	Customer Phone		
Customer Email			
Service Address			
Service Company			
Address			
Technician Name			
Technician Phone	Company Phone		
Technician Email			
Building Type	No. of Floors	No. of Indoor Units	No. of Outdoor Units
Brief Description of Equipment Condition			
Other Jobsite Observations			

4

This document does not supersede other technical documentation such as the installation, operation, and/or service manuals provided by Daikin North America, Inc. or its licensed distributor. Daikin products are subject to continuous improvement. Daikin reserves the right to modify product design, specification, and information in this publication without notice and without incurring any obligation.

BACK





Ductless Startup Checklist

4 Wire Communication Outdoor Residential Unit Inspection

Model name	Unit No.	System name and installation site	Piping length

Item	Method	Standard	Actual measurement	Judge-ment
Compressor	Measure using 500V megger (Measure U, V, and W terminals, and enter the minimum value)	1MΩ min.	Comp. 1 U V W NO NO NO	
Power supply voltage	Measure when unit does not operate and when compressor operates.	Within ±10% of rated voltage	L1 to Gnd L2 to Gnd L1 to L2 V V V	
Outdoor unit temperature data	By thermistor thermometer (Wait 15 minutes or more after startup to take measurement)	Outdoor temp. Suction air temp. Discharge air temp.	Outdoor temp. Suction air temp. Discharge air temp.	ng ng ng
Target disch. compressor temp.	Record from DChecker	DChecker measurement		ng
Actual compressor discharge pipe temp.	By Temperature Clamp/Temperature probe			ng
Outdoor discharge air temperature	By Temperature Clamp/Temperature probe	27°F to 45°F		ng
Suction pipe temperature	By Temperature probe	28°F to 50°F (operating conditions effect)		ng
Inlet Expansion valve temperature	By Temperature probe	Discharge air temp. + 27°F ± 1.4°F		
Super Heat (SH)	Calculation: = suction pipe temp. - evaporation temp.	9°F ± 5°F		ng
Expansion valve pulses	Using DChecker	Record pulses		pulses
ΔT	Calculation: = discharge air temp. - suction air temp.	18°F ± 2.7°F		
Protections	Record from DChecker	Value of 255 means inactive		

4 Wire Communication (Multi Split) Outdoor Residential Unit Inspection

Item	Method	Standard	Actual measurement				Judge-ment
			IDUA	IDUB	IDUC	IDUD	
Liquid pipe temperature	Measure by temperature probe	Navigation controller or service checker	ng	ng	ng	ng	ng
	Measure with DChecker		ng	ng	ng	ng	ng
Gas pipe temperature	Measure by temperature probe	Navigation controller or service checker	ng	ng	ng	ng	ng
	Measure with DChecker		ng	ng	ng	ng	ng
Expansion Valve Pulses	Measure with DChecker	Record pulses					

Judgement: G=Good, RM=Requires maintenance, RS=Requires service, GMS=Good after maintenance or service

Note: Enter NA for items that do not require inspection.

6 This document does not supersede other technical documentation such as the installation, operation, and/or service manuals provided to Ductless System dealers, but can be used in conjunction. Ductless products are subject to continuous improvements. Ductless reserves the right to make product design, specification, and hardware changes without notice.

BACK





Ductless Startup Checklist

4 Wire Communication Indoor Residential Unit Inspection (1 of 2)

Indoor Unit A (Use for single phase indoor unit)

	Model name	Unit No.	System name and installation site	Piping length
Indoor unit A				
Item	Method	Standard	Actual measurement	Judge-ment
Indoor unit temperature data	By thermometer thermometer (Wait approx. 15 minutes after startup to take measurement)	In cooling: $\Delta t \geq 23.8^{\circ}\text{F}$ or more for single splits In heating: $\Delta t \geq 36^{\circ}\text{F}$ or more for multi splits	Suction air temp.	Y/N
			Discharge air temp.	Y/N
			Temperature difference Δt	Y/N
Indoor heat exchanger temperature	Record from D-checker			Y/N

Judgement: G=Good, RM=Requires maintenance, RS=Requires service, GMS=Good after maintenance or service

Note: Enter NA for items that do not require inspection.

Indoor Unit B

	Model name	Unit No.	System name and installation site	Piping length
Indoor unit B				
Item	Method	Standard	Actual measurement	Judge-ment
Indoor unit temperature data	By thermometer thermometer (Wait approx. 15 minutes after startup to take measurement)	In cooling: $\Delta t \geq 23.8^{\circ}\text{F}$ or more for single splits In heating: $\Delta t \geq 36^{\circ}\text{F}$ or more for multi splits	Suction air temp.	Y/N
			Discharge air temp.	Y/N
			Temperature difference Δt	Y/N
Indoor heat exchanger temperature	Record from D-checker			Y/N


Judgement: G=Good, RM=Requires maintenance, RS=Requires service, GMS=Good after maintenance or service

Note: Enter NA for items that do not require inspection.



ELECTRICAL WIRING

- 208/230V Power Circuit to Outdoor Unit
- 208/230V Power Circuit to Closest Branch Port Box (Daisy Chain Wire to other BP Boxes)
- 18/2 AWG from Outdoor to Closest Branch Port (Daisy Chain Wire to other BP Boxes) 16 VDC
- 14/4 Strand Wire from BP Boxes to AHU's 5-50 fluctuating




DAIKIN
AIR INTELLIGENCE™


Always follow local codes

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.


SKYAIR WIRING (2 WIRE)




Separate Power Supplies



DUCTLESS WIRING: OUTDOOR POWERS INDOOR



**14/4
Non-Shielded
Stranded
Wire**



**1 to 2 =
208/230 VAC**

**2 to 3 =
5-50 VDC
Fluctuating**

**1,2,3 to G =
120 VAC**



Illustration shows Single Split connections, other applications may differ.

208/230V

DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

COMMUNICATION CIRCUIT DIAGNOSTICS

1. 2 to 3 = 5 to 50 VDC fluctuating (when operating properly)
2. Disconnect power to outdoor unit. Disconnect #3. With 3 disconnected, from the outdoor unit, power back up. Put voltage meter on continuity. Test from 1 to 3. You should hear a faint click. Then set meter on VDC and measure voltage on 2 and 3. Approximate voltage should be 50VDC. Power down. Reconnect #3 to terminal block.
3. Disconnect #3 at indoor unit. Reapply power. Measure DC voltage across 2 and 3. Measured voltage should be approximately 5VDC.
4. If/when 1 and 2 are crossed, a constant audible (beeping) will be heard.
5. If/when 2 and 3 are crossed, you will receive a U4 code.



COMMUNICATION
FLUCTUATING
VOLTAGE 5-50 VDC
TERMINALS 2-3



CAUTION!

LINE VOLTAGE WILL BE PRESENT ON TERMINAL 3
1, 2, AS WELL AS 3 TO GROUND WILL ALL READ
APPROX. 120VAC TO GROUND



DRY MODE ON DAIKIN DUCTLESS



DRY MODE

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible.
- Automatically controls temperature and airflow rate, so manual adjustment of the functions is unavailable.



POWERFUL MODE ON DAIKIN DUCTLESS



POWERFUL MODE

- Pushing the POWERFUL button on the remote control gives you a boost in cooling or heating power for a 20-minute period, even if the unit is already operating at high capacity.



POWERFUL MODE ON DAIKIN DUCTLESS



HOT START MODE

- Built into system. When the heating operation starts or when the unit changes from cooling to heating there is no cold draft released into the room.



AUTO RESTART MODE ON DAIKIN DUCTLESS



AUTO FAN SPEED

- To reduce operating sound and power consumption, the fan speed is automatically controlled by the micro-processor to suit the controller setting and prevailing room temperature.



AUTO RESTART MODE ON DAIKIN DUCTLESS



AUTO RESTART MODE

- The unit memorizes the operation mode, airflow and temperature settings. Should there be a power failure when the unit is in operation, it will automatically return to the same operating conditions when the power is restored.





DAIKIN COMFORT CONTROL APP




Always in control with the Daikin Comfort Control App

It can happen to anyone. You forgot to change the temperature of your heat pump system or air conditioner before leaving the house, or you will be delayed returning home and wish to avoid needlessly heating or cooling your home. What in the past would have resulted in wasted energy is no longer a problem. With the Daikin Comfort Control App and wireless interface adapter, you are always in control. You can use your tablet or smartphone to access your Daikin system via the internet. Fault conditions can also be detected remotely, allowing a quick response to problems.









To download Scan QR Code

Daikin Comfort Control App Screen Shots



Functions accessible via the Daikin Comfort Control App



-  **Auto Mode** Your Daikin system will change between cooling or heating to maintain the desired temperature range
-  **Fan Mode** The indoor unit fan will run to circulate the air in the space without cooling or heating
-  **Heating Mode** Your Daikin system will only run in heating mode to maintain the desired heating temperature
-  **Cooling Mode** Your Daikin system will only run in cooling mode to maintain the desired cooling temperature
-  **Dry Mode** Your Daikin system will continually work to dry the air without affecting the temperature in the space
-  **Schedule** Adjust or set a schedule remotely

Easy Installation

It is necessary to install a Wireless Interface Adapter on the indoor unit of the system. WPS (Wireless Protected Setup) functionality of the adapter allows for quick setup: once the app is launched and the user registers and logs in, the app will find all connected units within the network. See below list of approved units.



App functionality requires that a **BRP072A43** wireless Interface Adapter be connected to an approved Daikin system.

Compatibility

SYSTEM	MODELS
3P	FTX_NMY3U/PTC_NMY3U
Daikin AURORA	FTX_NMY3U/FVS_NMY3U
EV	FTXS_VV3U/RDS_VV3U
5V	FTX_NV3U
700V	CTXS_QV3UHS, FTXR_TV3UHS, CTXS_VV3U/PTC_VV3U, FVS_NMY3U, PDS_VV3U, CTGS_VV3U
EMUSA	FTXR_TV3UHS

Visit www.daikinint.com/wireless to learn more



Our continuing commitment to quality products may result in changes in specifications without notice.
© 2019 DAIKIN NORTH AMERICA LLC Houston, Texas, USA www.daikinint.com or www.daikin.com

PF-WLCA8-15

DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.



ComfortControl



AT&T

2:24 PM

83%

Home

--- Last update at 14:24 ---

No units found

Check that you are connected to the same wireless network that your adapter is connected to.

If you need to add your adapter, press "Add adapter".

Add adapter

Log in (Not at home)
"Out-of-Home"


DEMO mode

Frequently Asked Questions






ComfortControl





ComfortControl





ComfortControl



AT&T 2:25 PM 83%

Enter the password for "Verizon-MiFi7730L-3EA2"

Cancel Enter Password Join

Password |

You can also access this Wi-Fi network by bringing your iPhone near any iPhone, iPad, or Mac which has connected to this network and has you in their contacts.

Passwords

q w e r t y u i o p
a s d f g h j k l ñ
z x c v b n m
123 espacio Conectar





ComfortControl



AT&T 2:26 PM 83%

Enter the password for "Verizon-MiFi7730L-3EA2"

Cancel Enter Password Join

Password ••••••••

You can also access this Wi-Fi network by bringing your iPhone near any iPhone, iPad, or Mac which has connected to this network and has you in their contacts.


Passwords

1	2	3	4	5	6	7	8	9	0
-	/	:	;	()	\$	&	@	"
#+=	.	,	?	!	'	✕			
ABC	🌐	espacio					Conectar		






ComfortControl





ComfortControl





ComfortControl



AT&T 2:27 PM 82%

[Back](#) Add adapter

Start End

Is the POWER LED on continuously, does it blink, or is it off?

	<input checked="" type="checkbox"/> POWER A
	<input type="checkbox"/> POWER B
	<input type="checkbox"/> POWER C





ComfortControl




AT&T 2:27 PM 82%

[Back](#) Add adapter

Start End

Is the POWER LED on continuously, does it blink, or is it off?



	A
<input checked="" type="checkbox"/> POWER	
<input type="checkbox"/> POWER	B
<input type="checkbox"/> POWER	C





ComfortControl



AT&T 2:28 PM 82%

< Back Add adapter

Start End

Does your router have a WPS button?



For more information, see the manual of your router.

Yes

No





ComfortControl

DAIKIN
AIR INTELLIGENCE™

AT&T 2:29 PM 82%

[Back](#) Add adapter

Start End

Is the AP LED on continuously?

1

2

If the AP LED is blinking, the adapter is still starting up. Please wait a couple of seconds.

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.



ComfortControl



AT&T 2:29 PM 82%

< Back Add adapter

Start End

Make sure that you can easily see the right-hand side of the adapter, or that you have the sticker that is provided with the adapter at hand. The sticker contains the adapter's SSID (network name) and KEY (network password).

SSID: Daikin4F551033
KEY: 0539923086009

A

B





ComfortControl



AT&T 2:29 PM 82%

< Back Add adapter

Start End

1. Leave the app and go to your smartphone's wireless network settings.
2. Connect to the adapter by selecting its SSID from the available networks list and entering its KEY.

Settings
Wi-Fi
DaikinAP123456
PASSWORD:
CANCEL CONNECT

KEY: 05399230860209

3 Return to the app and press "Continue" if the connection with the adapter succeeded. Otherwise, select "Adapter not in the list".


Continue

Adapter not in the list





ComfortControl





ComfortControl

DAIKIN
AIR INTELLIGENCE™

AT&T 2:31 PM 81%

< Add adapter

Start End

Is the AP LED on continuously?

If the AP LED is blinking, the adapter is still starting up. Please wait a couple of seconds.

On continuously

Not lit

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.



ComfortControl



AT&T 2:31 PM 81%


< Back Add adapter

Start End


Make sure that you can easily see the right-hand side of the adapter, or that you have the sticker that is provided with the adapter at hand. The sticker contains the adapter's SSID (network name) and KEY (network password).

SSID: Daikin4F551033
KEY: 0539923086009

A



B





ComfortControl



AT&T 2:32 PM 81%

< Back Add adapter

Start End

Switch the adapter to RUN mode by pressing the MODE button for at least 3 seconds.

Wait until the adapter has restarted and the RUN LED starts blinking or turns on continuously.

Continue





ComfortControl

DAIKIN
AIR INTELLIGENCE™

AT&T 2:36 PM 80%

< Back Add adapter

Start End

Switch the adapter to AP mode by pressing the MODE button for at least 3 seconds.

Wait until the adapter has restarted and the AP LED turns on continuously.
A blinking AP LED means that the adapter is starting up.

Continue

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.



ComfortControl



AT&T 2:36 PM 80%

< Back Add adapter

Start End

1. Leave the app and go to your smartphone's wireless network settings.
2. Connect to the adapter by selecting its SSID from the available networks list and entering its KEY.

3 Return to the app and press "Continue" if the connection with the adapter succeeded. Otherwise, select "Adapter not in the list".


Continue

Adapter not in the list






ComfortControl






ComfortControl





ComfortControl





ComfortControl



AT&T 2:39 PM 79%

Add adapter

Start End

The adapter will restart and try to connect to your network.

When the adapter is successfully connected, the RUN LED turns on continuously.

If the RUN LED keeps blinking, the adapter failed to connect to the network.


On continuously

Blinking






ComfortControl





ComfortControl

DAIKIN
AIR INTELLIGENCE™



VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.



ComfortControl



Adapter settings	
Adapter network settings	
"Out-of-Home" (Not at home)	Off >
Other adapter settings	
Connection test	>
Adapter LEDs	<input checked="" type="checkbox"/>
Time	>
Adapter information	
Firmware version	2.9.0
IP address	192.168.1.18
Mac address	60:F1:89:DC:18:4B





ComfortControl



AT&T 2:40 PM 79%

[Back](#) Time

Current adapter date and time
2019/08/08 14:40:38

Time zone
New York >

Automatic DST ☒





ComfortControl



AT&T 2:40 PM 78%
[Back](#) Connection test


The LEDs on the adapter will blink for about 3 minutes.





ComfortControl


DAIKIN
AIR INTELLIGENCE™



VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.




ComfortControl





ComfortControl



PREVENTATIVE MAINTENANCE



MAINTENANCE CHECKLIST: OUTDOOR UNIT

Inspection Items	Inspection Method	Criteria (Benchmarks)
Fan Blades	Visual inspection	Check the rotating/mounting direction of the fan. Check that there is no obstacle in the air passage.
General condition of outdoor unit	Visual inspection	Check for rust, dirt and obstructions
Molex connectors	Visual inspection	Check interconnecting wires and molex plugs for proper connections
Subcooling EEV Inspection	Visual inspection	Remove motor head and check condition
Coil Fins	Visual inspection	Check for bent/damaged fins - use appropriate fin comb
Check Service valves	Visual inspection	Check condition. Check for leaking or missing caps
Check Internal piping	Visual inspection	Check for rub or wear marks on piping
Low voltage communications terminals	Check with screwdriver	Check terminal block connections are tight
External piping	Visual inspection	Look for broken/deteriorated insulation



DO NOT Connect gauges unless you suspect a refrigerant issue!!



MAINTENANCE CHECKLIST: INDOOR UNIT

Inspection Items	Inspection Method	Criteria (Benchmarks)
Blower wheel	Visual inspection	Check the mounting/rotating direction of the fan. Check that there is no obstacle in the air passage.
EEV	See supplement on page 12	See supplement on page 12
General condition of indoor unit	Visual inspection	Check for rust, dirt and obstructions
Molex connectors	Visual inspection	Check interconnecting wires and molex plugs for proper connections
Low voltage communications terminals	Check with screwdriver	Check that terminal block connections are tight
Flare nut connections	Verify with torque wrench	See supplement on page 14 for torque specs and procedure
Flare Nut Insulation	Check flare nut insulation	Verify in good condition
Filter Check	Visual inspection	Check dust accumulation or damage of filter
Float Safety on internal lift pump	Operation Inspection	Engage safety to validate operation. Check for free movement of float switch. See supplemental information on page 14 .
Condensate drain pan	Visual inspection	Check for rust, debris, or standing water
Condensate pipe check	Operate in cooling mode for 20 minutes minimum	No water leaks
Operating sound	Listen	No abnormal noise
Swing	Check motion with remote controller	Normal Operation
Error Code History	Check using controller	Enter present error code - NA if none



DAIKIN DUCTLESS EVAP COIL MAINTENANCE



- **Desolv by Rectorseal**
- **Use non-acid, non-foaming coil cleaners**
- **JUST Water is most preferred**


FUNCTIONAL OVERVIEW

WIRING DIAGRAMS AND REFRIGERANT PIPING




17 SERIES FAN MOTOR WIRING

Model: FTXB09/12AX-RXB09/12AX ; FTXN09/12AX-RXN09/12AX



FTXS15/18/24/30/36LVJU



8.2 Indoor Fan Motor Connector Check

Check No.02

CTXG, CTXS, FTXS, FVXS Series


1. Check the connection of connector.
2. Check motor power supply voltage output (pins 4 - 7).
3. Check motor control voltage (pins 4 - 3).
4. Check rotation command voltage output (pins 4 - 2).
5. Check rotation pulse input (pins 4 - 1).

S1 or S200

7	○	→	Motor power supply voltage (310 ~ 340 VDC)
6	○		Unused
5	○		Unused
4	○	—	GND
3	○	→	Motor control voltage (15 VDC)
2	○	→	Rotation command voltage (1~ 5 VDC)
1	○	←	Rotation pulse input

(R14225)

RXS15/18LVJU



5.8 Rotation Pulse Check on the Outdoor Unit PCB

Check No.16

Make sure that the voltage of $320 + 100 \text{ V} \sim 320 - 50 \text{ V}$ is applied.


1. Set operation off and power off. Disconnect the connector S70 or S71.
2. Check that the voltage between the pins 4 - 7 is 320 VDC.
3. Check that the control voltage between the pins 3 - 4 is 15 VDC.
4. Check that the rotation command voltage between the pins 2 - 4 is $0 \sim 6.5 \text{ VDC}$.
5. Keep operation off and power off. Connect the connector S70 or S71.
6. Check whether 4 rotation pulses ($0 \sim 15 \text{ VDC}$) are input at the pins 1 - 4 when the fan motor is rotated 1 turn by hand.

When the fuse is melted, check the outdoor fan motor for proper function.

If NG in step 2 → Defective PCB → Replace the outdoor unit PCB (main PCB).


If NG in step 4 → Defective Hall IC → Replace the outdoor fan motor.

If OK in both steps 2 and 4 → Replace the outdoor unit PCB (main PCB).



(R20507)

FTXR09/12/18TVJUW(S), CTXG09/12/18QVJUW(S)



Wiring diagram

FG : Frame ground
 F1U, F2U : Fuse
 H1P, H2P : Pilot lamp
 R1T, R2T : Thermistor
 S25-S200 : Connector
 S1W : Operation switch
 S1C : Limit switch
 X1M : Terminal strip
 BZ : Buzzer
 M1F : Fan motor
 M1S-M3S : Swing motor
 M1 : Stepper motor
 A1P-A3P : Printed circuit board
 TRC : Transmission circuit
 WRC : Wireless remote control
 IES : Intelligent Eye sensor
 (A) : Rectifier

SR : Signal receiver
 (GND) : Ground
 H1-H3 : Harness
 MR10 : Magnetic relay
 V1 : Varistor
 C101, C102 : Capacitor

NOTE When the main power is turned off and then back on again, operation will resume automatically.

8.1 Thermistor Resistance Check


Check No.01

Disconnect the connectors of the thermistors from the PCB, and measure the resistance of each thermistor using a multimeter.

The data is for reference purpose only.

Thermistor temperature		Resistance (kΩ)
°C	°F	
-20	-4	197.8
-15	5	148.2
-10	14	112.1
-5	23	85.60
0	32	65.93
5	41	51.14
10	50	39.99
15	59	31.52
20	68	25.02
25	77	20.00
30	86	16.10
35	95	13.04
40	104	10.62
45	113	8.707
50	122	7.176


(R25°C (77°F) = 20 kΩ, B = 3950 K)



- When the room temperature thermistor is soldered on a PCB, remove the PCB from the control PCB to measure the resistance.
- When the connector of indoor heat exchanger thermistor is soldered on a PCB, remove the thermistor and measure the resistance.

COLORED WIRING DIAGRAM

5MXS48TVJU



8.5 Electronic Expansion Valve Check

Check No.12

Conduct the following to check the electronic expansion valve (EV).

1. Check if the EV connector is correctly inserted in the PCB. Match the EV unit number and the connector number.
2. Turn the power off and on again, and check if all the EVs generate a latching sound.
3. If any of the EVs does not generate a latching sound in the above step 2, disconnect that connector and check the continuity using a multimeter.
Check the continuity between the pins 5 - 1, 5 - 2, 5 - 3, 5 - 4. If there is no continuity between the pins, the EV coil is faulty.
4. If no EV generates a latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the continuity is confirmed in the above step 3, mount a good coil (which generated a latching sound) in the EV unit that did not generate a latching sound, and check if that EV generates a latching sound.
• If a latching sound is generated, the outdoor unit PCB is faulty.
• If a latching sound is not generated, the EV unit is faulty.


Note: Please note that the latching sound varies depending on the valve type.

If the system keeps operating with a defective electronic expansion valve, the following problem may occur.

Valve opening position	Possible problem	Check method
Open	Cooling: <ul style="list-style-type: none"> Flowing noise of refrigerant in the unit which is not in operation Water leakage at the unit which is not in operation Operation halt due to anti-icing function Heating: <ul style="list-style-type: none"> Flowing noise of refrigerant in the unit which is not in operation The unit does not heat the room. 	Reset power supply and conduct cooling operation unit by unit. <div style="border: 1px solid black; padding: 5px; margin: 5px 0;">Check the liquid pipe temperature of no-operation unit.</div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin: 5px 10px;">Almost the same as the outdoor temperature?</div> <div style="margin-left: 10px;"> NO → The EV is not defective. YES → Replace the EV of the room. (R15019) </div> </div>
Close	Cooling: <ul style="list-style-type: none"> The problem unit does not cool the room. Only the problem unit is in operation, the unit starts pump down. (The low pressure of the unit becomes vacuum.) Abnormal discharge pipe temperature Heating: <ul style="list-style-type: none"> Refrigerant shortage due to stagnation of liquid refrigerant inside the faulty indoor unit The unit does not heat the room. Abnormal discharge pipe temperature 	Reset power supply and conduct cooling operation unit by unit. <div style="border: 1px solid black; padding: 5px; margin: 5px 0;">Check the low pressure.</div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin: 5px 10px;">Does the pressure become into vacuum zone?</div> <div style="margin-left: 10px;"> NO → The EV is not defective. YES → Replace the EV of the room. (R15020) </div> </div>

COLORE

RMXS48LVJU





L1-RED	L2-BLU	K2R	MAGNETIC RELAY (Y2S)	S1PH	PRESSURE SWITCH (HIGH)
A1P	PRINTED CIRCUIT BOARD (MAIN)	K3R	MAGNETIC RELAY (Y3S)	V1R	POWER MODULE
A2P	PRINTED CIRCUIT BOARD (SERVICE)	K4R	MAGNETIC RELAY (E1HC)	V2R, V3R	DIODE MODULE
A3P	PRINTED CIRCUIT BOARD (NOISE FILTER)	K5R	MAGNETIC RELAY	V1T	IGBT
A4P	PRINTED CIRCUIT BOARD (CH SELECTOR)	L1R	REACTOR	X1M	TERMINAL STRIP POWER SUPPLY
BS1-5	PUSH BUTTON SWITCH	M1C	MOTOR (COMPRESSOR)	X2M	TERMINAL STRIP CONTROL
C1-4	CAPACITOR	M1F	MOTOR (FAN UPPER)	X1M	TERMINAL STRIP CH SELECTOR (AIR)
DS1	DIP SWITCH	M2F	MOTOR (FAN LOWER)	Y1E	ELECTRONIC EXPANSION VALVE (MAIN)
E1HC	CRANKCASE HEATER	PS	POWER SUPPLY	Y3E	ELECTRONIC EXPANSION VALVE (SUB COOL)
F1U, F2U	FUSE (T 6.3A/250V)	R1	RESISTOR	Y2S	SOLENOID VALVE (4 WAY VALVE)
F2U	FUSE (T 5.0A/250V)	R2	RESISTOR	Y2S	SOLENOID VALVE (HOT GAS)
H1P-8P	PLOT LAMP (SERVICE MONITOR ORANGE)	R1T	THERMISTOR (AIR)	Y3S	SOLENOID VALVE (UL CIRCUIT)
H1P-8P	PLOT LAMP (SERVICE MONITOR GREEN)	R2T	THERMISTOR (MTC DISCHARGE)	Z1C-7C	NOISE FILTER (FERRITE CORE)
H1P-8P	PLOT LAMP (SERVICE MONITOR BLUE)	R3T	THERMISTOR (SUCTION1)	Z1F-4F	NOISE FILTER
H1P-8P	PLOT LAMP (SERVICE MONITOR RED)	R4T	THERMISTOR (COIL)		CH SELECTOR
H1P-8P	PLOT LAMP (SERVICE MONITOR YELLOW)	R5T	THERMISTOR (SUCTION2)	S1S	SELECTOR SWITCH (AW/COOL/HEAT)
H1P-8P	PLOT LAMP (SERVICE MONITOR PURPLE)	R6T	THERMISTOR (SUBCOOL)	S2S	SELECTOR SWITCH (COOL/HEAT)
H1P-8P	PLOT LAMP (SERVICE MONITOR BROWN)	R7T	THERMISTOR (LIQUID)		CONNECTOR OF OPTION ADAPTOR
H1P-8P	PLOT LAMP (SERVICE MONITOR GREEN)	F1NTH	THERMISTOR (FIN)	X37A	CONNECTOR
K1M	MAGNETIC CONTACTOR	S1NPH	PRESSURE SENSOR (HIGH)	NOTE14	OPTION ADAPTOR POWER SUPPLY
K1R	MAGNETIC RELAY (Y1S)	S1NPL	PRESSURE SENSOR (LOW)		

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.


8.6 Four Way Valve Performance Check

Check No.13



COLORED WIRING DIAGRAM


BPMKS049A3U




REFRIGERANT PIPING SCHEMATICS



RXN12NMVJU, RX12NMVJU




FTXN12NMVJU, FTX09/12NMVJU



COLORED REFRIGERANT PIPING SCHEMATIC

4MXL36TVJU




DAIKIN
AIR INTELLIGENCE™

VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

COLORED REFRIGERANT PIPING SCHEMATIC

BPMKS049A3U



TROUBLESHOOTING





Simple Self-Diagnosis by Malfunction Code

DAIKIN INDUSTRIES, LTD.
After Sales Service Division
(SM-TS2)

Data code		0	1	2	3	4	5	6	7	8	9	A	C	E	F	H	J
Division	Indoor Unit	A	External protection device activated	Malfunction of indoor unit PCB	Malfunction of drain level system	Malfunction of freezing protection	High pressure control in heating, freeze-up protection control in cooling	Malfunction of fan motor	Malfunction of swing flap motor	Malfunction of power supply or AC input overcurrent	Malfunction of electronic expansion valve	Heater overheat	Stop due to low water level	Low water level, no water supply	Malfunction of humidifier system	Malfunction of dust collector or air cleaner	Malfunction of capacity setting (indoor unit PCB)
		C	Malfunction of sensor system (unit)	Failure of transmission between indoor unit PCB and sub-PCB	Malfunction of drain level sensor	Malfunction of input pipe thermostat for heat exchanger	Malfunction of gas pipe thermostat for heat exchanger	Malfunction of fan motor sensor or fan control driver	Front panel driving motor built	Malfunction of AC input current sensor system	Malfunction of suction air thermostat	Malfunction of discharge air thermostat	Malfunction of humidity sensor system	Malfunction of switch box thermostat	Malfunction of high pressure switch	Malfunction of thermal storage unit	Malfunction of thermal sensor in remote controller
		E	Protection device activated (unit)	Defect of outdoor unit PCB	Malfunction of cold room thermostat	Actuation of high pressure switch (HPS)	Actuation of low pressure switch (LPS)	Inverter compressor motor or overheat	STD compressor motor overcurrent/lock	Malfunction of outdoor unit fan motor system	Overcurrent of inverter compressor	Malfunction of electronic expansion valve coil	Malfunction of four way valve solenoid	Malfunction of entering water temperature	Malfunction of drain water level	Malfunction of thermal storage unit	Malfunction of cooling water pump
Outdoor Unit	F	F	Malfunction of discharge pipe temperature	Malfunction of suction pipe temperature	Malfunction of low pressure switch (HPS)	Malfunction of low pressure switch (LPS)	Malfunction of suction pipe thermostat	Malfunction of compressor motor overheat	Abnormal high pressure or refrigerant overcharged	Malfunction of position detection sensor	Malfunction of outdoor fan signal	Malfunction of compressor input (CT)	Malfunction of outdoor air thermostat	Malfunction of discharge air thermostat	Malfunction of low pressure sensor	Abnormal oil pressure	Abnormal high temperature of refrigerant oil
		H	Malfunction of sensor system of compressor	Malfunction of room temperature sensor or humidity unit damper	Malfunction of power supply sensor	Malfunction of high pressure switch (HPS)	Malfunction of low pressure switch (LPS)	Malfunction of compressor motor overheat	Malfunction of position detection sensor	Malfunction of outdoor fan signal	Malfunction of compressor input (CT)	Malfunction of outdoor air thermostat	Malfunction of discharge air thermostat	Malfunction of (hot) water temperature thermostat	Malfunction of drain water level	Alarm in thermal storage unit or storage controller	High room temperature alarm
		J	Miswiring of thermostat	Malfunction of pressure sensor	Malfunction of current sensor of compressor	Malfunction of discharge pipe thermostat	Malfunction of low pressure equivalent saturation temperature sensor system	Malfunction of suction pipe thermostat	Malfunction of heat exchanger thermostat	Malfunction of thermostat (Refrigerant circuit)	Malfunction of thermostat (Refrigerant circuit)	Malfunction of thermostat (Refrigerant circuit)	Malfunction of high pressure sensor	Malfunction of low pressure sensor	Malfunction of oil level sensor or sub-tank thermostat	Malfunction of oil temperature thermostat	Malfunction of engine room temp. sensor or exhaust temp.
System	L	L	Malfunction of inverter system	Malfunction of inverter PCB	Electrical box temperature rise	Malfunction of inverter radiating fin temperature rise	Inverter instantaneous overcurrent (DC output)	Inverter instantaneous overcurrent (AC output)	Total input overcurrent	Malfunction of overcurrent inverter compressor	Malfunction of compressor startup error (Stal prevention)	Malfunction of power fanstart	Malfunction of transmission between control and inverter PCB	Malfunction of oil pressure sensor	Malfunction of oil level sensor or sub-tank thermostat	Engine startup error	Malfunction of generator converter
		P	Shortage of refrigerant amount (thermal storage unit)	Power voltage imbalance or overcurrent	Automatic refrigerant charge operation stop	Malfunction of thermostat in switch box	Malfunction of radiating fin temperature sensor	Malfunction of DC current sensor	Malfunction of AC or DC output current sensor	Malfunction of total input current sensor	Heat exchanger heating protection during automatic refrigerant charging	Malfunction of transmission between remote controller	Automatic refrigerant charge operation completed	Refrigerant cylinder during automatic refrigerant charging	Automatic refrigerant charge operation nearly completed	Malfunction of starter actuation	Refrigerant cylinder during automatic refrigerant charging
		U	Shortage of refrigerant	Reverse phase, open phase	Check operation not executed or transmission error	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit	Malfunction of transmission between indoor and outdoor unit
Others	M	M	Malfunction of remote controller PCB	Malfunction of PCB	Ozone density abnormal	Contaminated sensor error	Malfunction of thermostat for indoor air (HRO)	Malfunction of thermostat for outdoor air (HRO)	Supply air passage closed	Exhaust air passage closed	Malfunction of dust collection unit (HRO)	Malfunction of damper system (HRO)	Replace the humidity element	Replace the desiccating catalyst	Simplified remote controller malfunction (HRO)	Door switch open (HRO)	Replace the high efficient filter
		6	External protection device activated (HRO)	Malfunction of PCB	Ozone density abnormal	Contaminated sensor error	Malfunction of thermostat for indoor air (HRO)	Malfunction of thermostat for outdoor air (HRO)	Supply air passage closed	Exhaust air passage closed	Malfunction of dust collection unit (HRO)	Malfunction of damper system (HRO)	Replace the humidity element	Replace the desiccating catalyst	Simplified remote controller malfunction (HRO)	Door switch open (HRO)	Replace the high efficient filter
		7	System No. 2 Compressor overheat	System No. 2 Compressor overcurrent	System No. 2 Fan motor overcurrent	System No. 2 Actuation of high pressure switch (HPS)	System No. 2 Actuation of low pressure switch (LPS)	System No. 2 Malfunction of low pressure sensor	System No. 2 Malfunction of high pressure sensor	System No. 2 Malfunction of fan inter lock	System No. 2 Malfunction of fan inter lock	System No. 2 Malfunction of compressor current sensor	System No. 2 Malfunction of pump inter lock	System No. 1 Malfunction of suction pipe thermostat 1 for heating	System No. 1 Malfunction of suction pipe thermostat 2 for heating	System No. 1 Malfunction of suction pipe thermostat 1 for heating	System No. 1 Malfunction of suction pipe thermostat 2 for heating
Others	8	8	Malfunction of entering water temperature thermostat	Malfunction of leaving water temperature thermostat or drain pipe heater	System No. 1 Malfunction of refrigerant thermostat	System No. 2 Malfunction of refrigerant thermostat	System No. 1 Malfunction of heat exchanger thermostat	System No. 2 Malfunction of heat exchanger thermostat	System No. 1 Malfunction of discharge pipe thermostat	System No. 2 Malfunction of discharge pipe thermostat	System No. 1 Malfunction of thermal storage unit	System No. 2 Malfunction of thermal storage unit	System No. 1 Malfunction of thermal storage unit	System No. 2 Malfunction of thermal storage unit	System No. 1 Malfunction of thermal storage unit	System No. 2 Malfunction of thermal storage unit	System No. 1 Malfunction of thermal storage unit
		9	Abnormal filled water quantity or abnormal AXP	System No. 2 Malfunction of electronic expansion valve	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat	System No. 2 Malfunction of suction pipe thermostat




Self-Diagnosis by Remote Controller (Residential Air-conditioner)

In case of ARC447A

[Check Method]

With the wireless remote controller supplied with the unit, or sold separately, malfunction codes by failure diagnosis can be confirmed. (Press timer cancel button down for 5 seconds continuously.)



1. Hold the timer cancel button down for 5 seconds, with the remote controller set toward the indoor unit.
2. The temperature display on the remote controller changes to the error code display and a long beep notifies this indication change.

Note:

To cancel indication of malfunction code, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

In case of ARC455A, ARC452A, ARC433B, ARC423A, ARC417A [Check Method 1]

1. When the timer cancel button is held down for 5 seconds, a "00" indication flashes on the temperature display section.



2. Press the timer cancel button repeatedly until a continuous beep is produced.
 - The code indication changes in the sequence shown below, and notifies with a long beep.

<In case of ARC433B67, 68, 69, 76>

No.	Code	No.	Code	No.	Code
1	00	12	E7	23	H0
2	UV	13	H0	24	E1
3	F3	14	U3	25	P4
4	E6	15	R3	26	L3
5	L5	16	R1	27	L4
6	R6	17	E4	28	H6
7	E5	18	C5	29	H9
8	F6	19	H9	30	U2
9	C9	20	U6	31	U4
10	U0	21	U9	32	E8
11	E7	22	H5	33	H4

Note:

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

[Check Method 2]

1. Press the 3 buttons (TEMP ▲, TEMP ▼, MODE) simultaneously to enter the diagnosis mode.

The figure of the ten's place blinks.

★ Try again from the start when the figure does not blink.



2. Press TEMP ▲ or ▼ button and change the figure until you hear the sound of "beep" or "pi pi".



3. Diagnose by the sound.

★ "pi": The figure of the ten's place does not accord with the malfunction code.

★ "pi pi": The figure of the ten's place accords with the error code but the one's not.

★ "beep": The both figures of the ten's and one's place accord with the malfunction code.



4. Press the MODE button.

The figure of the one's place blinks.



5. Press the TEMP button.

Press TEMP ▲ or ▼ button and change the figure until you hear the sound of "beep".



6. Diagnose by the sound.

★ "pi": The figure of the ten's place does not accord with the malfunction code.

★ "pi pi": The figure of the ten's place accords with the error code but the one's not.

★ "beep": The both figures of the ten's and one's place accord with the error code.



7. Determine the malfunction code.

The digits indicated when you hear the "beep" sound are error code.



8. Press the MODE button to exit from the diagnosis mode.

The display "T-" means the trial operation mode.




9. Press the ON/OFF button twice to return to the normal mode.



Note:

When the remote controller is left untouched for 60 seconds, it returns to the normal mode.



Meters need to Read

- Volts A/C – 500
- Volts D/C – 600
- Ohms- 10 Mega-ohms.
- Diode Check

Multi Split 2/3/4MXS Diagnostic by Outdoor Unit PCB

- 

●: ON, ●: OFF, ◐: Blinks

Red: OFF in normal condition



COMMON ERRORS: U4 FAULT CODE

How would I handle U4:


- 1) Proper power supply to outdoor unit(187 to 253VAC) matching voltage at 1 and 2
- 2) NO Pulsing DC circuit between indoor and outdoor units (5 to 50 VDC at legs 2 and 3 on outdoor (**reading of steady voltage**))
- 3) All wires off 1,2 and 3 at outdoor unit
- 4) Set meter to continuity and test 1 & 3. Look for light on board. If light shows, proceed to step 5. No light? Bad board. Need to isolate parts of outdoor unit, test fan motor, compressor & LEV
- 5) Between 2 and 3 terminals do you have 50ish vdc? if yes outdoor seems good
- 6) Add wires to outdoor take wires off indoor see if same vdc on wires as outdoor
- 7) If yes add wires and remove the fan motor indoors see if corrects? If yes fan motor caused issue.




DUCTLESS WIRING: OUTDOOR POWERS INDOOR

PWEZ14450 50ft

PWEZ144250 250ft



**14/4
Non-Shielded
Stranded
Wire**



240VAC

5-50 VDC

1
2
3
G

DAIKIN
AIR INTELLIGENCE™



VIRGINIA AIR
VIRGINIA AIR DISTRIBUTORS, INC.

BLUETOOTH DAIKIN D - CHECKER

Daikin Monitoring Tool APP



2:02 PM 87%

AC Monitoring Tool


20180411 No alarm

2018-04-11 10:01:55 Err:0

Basic data			
Operation mode	Cooling	Outdoor temp.	59.9 (F)
Discharge temp.	50.6 (F)	INV current	0.50
INV frequency	54		
Control			
Op mode	Cooling	Defrost op.	OFF
Error code	0	Trigl. Disch.Temp.	54.0 (F)
Max Hz(peak cut)	255	Max Hz(Hz prto)	255
Max Hz(Td)	255	Max Hz(INV cur)	255
Max Hz(rps)	68	Min Hz(rps)	14
Comp stop timer	0	OD fan dly timer	60
Sensor			
Outdoor air temp.	59.9 (F)	ODU hex temp.	54.1 (F)
Disch temp.	50.6 (F)	Fin temp.	59.9 (F)
Operation cur(A)	0.50	AC voltage (V)	210.5
Actuator			
Indoor unit			
Indoor op. mode	Cooling		
Indoor err code	0		
Indoor delta-D	1		
Indoor ret temp.	54.4 (F)		
Indoor hex temp.	53.5 (F)		
Indoor fan freq.	1250		
Indoor fan tap	H		
Indoor flap angle	P0		
Indoor louver angle	P0		
Indoor setpoint	55.3 (F)		
Indoor fan dly timer	0		



D-Checker



D-Checker

Data viewer ((REC_ONLY))

Network map (F1) | Graph view (F2) | Cursor A data (F3) | Data b/w CursorA/B (F4) | Label editor (F5)

		Data name	Value
1		Operation Mode	Cooling
2	1	D Defrost Operation	OFF
3		Malfunction Code	0
4	1	A Target Discharge Temp.	122.90 (F)
5	2	A Max Hz by Freeze Protection	46
6	2	A Max Hz by Peak Cut ctrl(rps)	255
7	2	A Max Hz by Discharge Temp. c	255
8	2	A Max Hz by Input Current ctrl	255
10	2	A Maximum Comp. Frequency(r	46
11	2	A Minimum Comp. Frequency(r	1
12		Comp. Stop Timer (sec)	0
13		Outdoor Fan Delay Timer(sec)	70

		Data name	Value
45	0	1 A Outdoor Air Temp.	70.70 (F)
46	1	1 A Outdoor Heat Exchanger Tem	83.30 (F)
47	2	2 A Discharge pipe temp.	122.00 (F)
62	1	A Fin Temp.	107.60 (F)
64	1	A Operation Current(A)	2.25
65	3	A Power Source Voltage(V)	240.1

		Data name	Value
73		D Compressor	ON
74	3	2 A Compressor Frequency(rps)	46
75	2	A Target Comp. Frequency(rps)	46
76	3	A Target Out Fan1 Frequency(r	820
77	4	3 A Out Fan 1 Frequency(rpm)	820
82		D 4 Way Valve ON/OFF	OFF
83		D 4 Way Valve Op. Mode	Cooling
84	5	3 A Port A EV (pls)	145

		Data name	Value
97		Room A Op. Mode	Cooling
99		Room A Malfunction Code	0
102	1	A Room A Delta-D	9
103	6	1 A Room A Suction Air Temp.	71.60 (F)
104	7	1 A Room A Heat Exchanger Tem	46.40 (F)

		Data name	Value
110	3	A Room A Fan Frequency	1210
111		Room A Fan Tap	H
112		Room A Flap Angle	P0
114		Room A Louver Angle	P0
115	1	A Room A R/C Setpoint	64.40 (F)

		Data name	Value
119		Room A Airflow Setup (cool)	H
122		Room A Airflow Setup (heat)	H
123		Room A In/Out Transmission	Normal


Cursor A (Left click) Cursor B (Right click)

2016/11/09 09:25:25 2016/11/09 09:34:25

Print Screen (F9) Back (Esc)




MonitoringTool





Monitoring Tool





MonitoringTool




AT&T 1:58 PM 89%

Enter PIN

Cancel BTSC Pair

PIN ●●●●


Ringer



1 2 3
ABC DEF

4 5 6
GHI JKL MNO


7 8 9
PQRS TUV WXYZ

0 






MonitoringTool





MonitoringTool





MonitoringTool



Settings 1:58 PM 89%

Common settings Log

Service office	Virginia Air
Responsible person	Juan
Display mode	1 Column
Sampling rate	5 seconds
Period	<input type="radio"/> 00h 00m
	<input checked="" type="radio"/> Manual stop
Unit of measure	psi/F
Connection Type	Bluetooth

☐ ☒





MonitoringTool



Settings 1:59 PM 89%		
AC Monitoring Tool		
Customer selection (Please select the customer)		
Add new		REC only
1	(REC only) Sent	>
2	20190805 Test	>





MonitoringTool



Settings 2:00 PM 89%

AC Monitoring Tool

Customer information

Customer ID	20190808
Customer Name	Training room 2
Div./Sec./Dept.	
Person Name	
Phone	
Address	
Fax	
Mail	
Remarks	
Last update	

<<2>>

1 2 3 4 5 6 7 8 9 0

- / : ; () \$ & @ "

#+= . , ? ! ' <

ABC [Globe] [Microphone] espacio Siguiente





MonitoringTool



Settings 2:00 PM 88%

AC Monitoring Tool

Network map selection
(Please select the network map to use)

20190808
Training room 2
Add new





MonitoringTool



Settings 2:00 PM 88%

← AC Monitoring Tool

Select model

Customer ID	(REC only)
Map name	20190808140051
System name	20190808140051
Model	
Product Type	Auto select

🔗

Protocol	Indoor units
----------	--------------

Data label file

❌

✅





MonitoringTool



Settings 2:01 PM 88%

AC Monitoring Tool

Select model

Customer ID	(REC only)
Map name	20190808140051
System name	20190808140051
Model	
Product Type	Auto select

Protocol 400 units

Data label file Detecting...

✖ ✓





MonitoringTool



Settings 2:01 PM 88%

← AC Monitoring Tool

Select model

Customer ID	(REC only)
Map name	20190808140051
System name	20190808140051
Model	
Product Type	Auto select

Ⓛ

Protocol	M	Indoor units	1
----------	---	--------------	---

Data label file

Unselected

✗ ✓





MonitoringTool



Settings 2:01 PM 88%

← AC Monitoring Tool

Select model

Customer ID	(REC only)
Map name	20190808140051
System name	20190808140051
Model	
Product Type	Auto select

Ⓢ

Protocol	M	Indoor units	1
----------	---	--------------	---

Data label file

Unselected

Unselected

Multi_Split

Single_Split

Cancel





MonitoringTool



Settings 2:01 PM 88%

← AC Monitoring Tool

Select model

Customer ID	(REC only)
Map name	20190808140051
System name	20190808140051
Model	
Product Type	Auto select

ⓧ

Protocol	M	Indoor units	1
----------	---	--------------	---

Data label file

Single_Split

ⓧ

✓





MonitoringTool



Settings 2:02 PM 88%

AC Monitoring Tool

(REC only) No alarm

Rec 00:00:00 Err:0

Basic data Control Sensor Actuator Indoor unit

Operation mode	Cooling
Outdoor temp.	71.6 (F)
Discharge temp.	76.1 (F)
INV current	1.00
INV frequency	24

Icons: Line graph, Gear, Double arrows, Red circle, House





MonitoringTool



Settings 2:02 PM 88%

AC Monitoring Tool

(REC only) No alarm

Rec 00:00:00 Err:0

Basic data Control Sensor Actuator Indoor unit

Op mode	Cooling
Defrost op.	OFF
Error code	0
Trgt. Dsch.Temp.	32.0 (F)
Max Hz(peak cut)	255
Max Hz(frz prtc)	255
Max Hz(Td)	255
Max Hz(INV cur)	255
Max Hz (rps)	24
Min Hz (rps)	16
Comp stop timer	0
OD fan dly timer	70

Icons: Line graph, Gear, Double arrows, Red circle, House





MonitoringTool



Settings

2:02 PM

88%

AC Monitoring Tool

(REC only)No alarm

Rec 00:00:00

Err:0

Basic data

Control

Sensor

Actuator

Indoor unit

Outdoor air temp.	71.6 (F)
ODU hex temp.	75.2 (F)
Disch temp.	77.0 (F)
Fin temp.	86.0 (F)
Operation cur(A)	1.00
AC voltage (V)	200.0





MonitoringTool



Settings

2:02 PM

88%

AC Monitoring Tool

(REC only)No alarm

Rec 00:00:00

Err:0

Basic data

Control

Sensor

Actuator

Indoor unit

Compressor	ON
Comp. (rps)	24
Trgt comp. (rps)	24
Trgt o_fan1 (rpm)	710
O_fan1 (rpm)	710
4way valve on/off	OFF
4way vlv op. mode	Cooling
Port A EV (pls)	224





MonitoringTool



Settings

2:02 PM

88%

AC Monitoring Tool

(REC only)No alarm

Rec 00:00:00

Err:0

Basic data

Control

Sensor

Actuator


Indoor unit

Indoor op. mode	Cooling
Indoor err code	0
Indoor delta-D	9
Indoor ret_temp.	71.6 (F)
Indoor hex temp.	62.6 (F)
Indoor fan freq	500
Indoor fan tap	LL
Indoor flap angle	P0
Indoor louver angle	P0
Indoor setpoint	64.4 (F)
Indoor airflow (C)	L
Indoor airflow (H)	L
Indoor in/out trnsm	Normal





MonitoringTool





MonitoringTool



Settings 2:02 PM 88%

AC Monitoring Tool

(REC only) No alarm

Rec 00:00:00 Err:0

Basic data Control Sensor Actuator Indoor unit

Indoor op. mode	Cooling
Indoor err code	0
Indoor delta-D	9
Indoor ret. temp.	71.6 (F)
Indoor he	
Indoor fan	
Indoor fan	
Indoor fla	
Indoor lou	
Indoor setpoint	64.4 (F)
Indoor airflow (C)	L
Indoor airflow (H)	L
Indoor in/out trnsm	Normal

Start recording. Proceed?

Sampling rate:5seconds
Manual stop

No Yes

Graph Settings Back Stop Home





MonitoringTool



AT&T

2:03 PM

87%

AC Monitoring Tool

(REC only)No alarm

Rec 00:00:25

Err:0

Basic data

Control

Sensor

Actuator

Indoor unit

Indoor op. mode	Cooling
Indoor err code	0
Indoor delta-D	9
Indoor ret_temp.	72.5 (F)
Indoor hex temp.	54.5 (F)
Indoor fan freq	500
Indoor fan tap	LL
Indoor flap angle	P0
Indoor louver angle	P0
Indoor setpoint	64.4 (F)
Indoor airflow (C)	L
Indoor airflow (H)	L
Indoor in/out trnsm	Normal





MonitoringTool



AT&T 2:03 PM 87%

AC Monitoring Tool

(REC only) No alarm

Rec 00:00:55 Err:0

Basic data Control Sensor Actuator Indoor unit

Op mode	Cooling
Defrost op.	OFF
Error code	0
Trgt. Dsch.Temp.	32.0 (F)
Max Hz(peak cut)	255
Max Hz(fr	
Max Hz(Tc	
Max Hz(IN	
Max Hz (rps)	24
Min Hz (rps)	16
Comp stop timer	0
OD fan dly timer	70

Finish recording. Proceed?

No Yes

Graph Settings Back Home





MonitoringTool



AT&T

2:06 PM

87%

AC Monitoring Tool

(REC only)No alarm

Rec 00:00:55

Err:0

Basic data

Control

Sensor

Actuator

Indoor unit

Indoor op. mode	Cooling
Indoor err code	0
Indoor delta-D	3
Indoor ret_temp.	71.6 (F)
Indoor hex temp.	50.9 (F)
Indoor fan freq	500
Indoor fan tap	LL
Indoor flap angle	P0
Indoor louver angle	P0
Indoor setpoint	71.6 (F)
Indoor airflow (C)	L
Indoor airflow (H)	L
Indoor in/out trnsm	Normal





MonitoringTool



AC Monitoring Tool

(REC only) No alarm

Rec 00:00:55 Err:0

Basic data Control Sensor Actuator Indoor unit

Indoor op. mode	Cooling
Indoor err code	0
Indoor delta-D	0
Indoor ret. temp.	72.5 (F)
Indoor he	
Indoor fan	
Indoor fan	
Indoor fla	
Indoor lou	
Indoor setpoint	75.2 (F)
Indoor airflow (C)	L
Indoor airflow (H)	L
Indoor in/out trnsm	Normal

Do you want to return to main menu?


No Yes

Navigation icons: Line graph, Settings, Double arrows, Red circle, Home





MonitoringTool





MonitoringTool



AT&T 2:12 PM 86%		
AC Monitoring Tool		
Network map selection (Please select the network map to use)		
(REC only)		
1	20190805163717 20190805163805 Sent	>
2	20190808140051 20190808140200	>





MonitoringTool



AT&T 2:12 PM 86%

← AC Monitoring Tool

(REC only) No alarm

2019-08-08 14:02:30 Err:0

Basic data Control Sensor Actuator Indoor unit

Operation mode	Cooling
Outdoor temp.	71.6 (F)
Discharge temp.	77.9 (F)
INV current	1.00
INV frequency	24

📈 ⚙️ ↔️ ○ 🏠





MonitoringTool



AT&T 2:13 PM 85%

← AC Monitoring Tool

(REC only) No alarm

2019-08-08 14:02:30 Err:0

Basic data	Control	Sensor	Actuator	Indoor unit
Operation mode	Cooling			
Outdoor temp.	71.6 (F)			
Discharge temp.	77.9 (F)			
INV current	1.00			
INV frequency	24			

Display mode

Select indoor unit

Select Item

Cancel





MonitoringTool



AT&T 2:13 PM 85%

AC Monitoring Tool

Network map selection
(Please select the network map to use)

(REC only)


<input type="checkbox"/>	1	20190805163717	20190805163805	>
			Sent	
<input checked="" type="checkbox"/>	2	20190808140051	20190808140200	>

✓ ♻️ ✉️





MonitoringTool





MonitoringTool




AT&T 2:14 PM 85%

Cancel New Message Send

To:

Cc/Bcc, From: jchc808@ymail.com

Subject:



(REC only).tgz

Juan Cardona






MonitoringTool





MonitoringTool



WHO IS READY FOR SOME HANDS ON EXERCISES??



END OF TRAINING SURVEY

- Please scan the below QR code and take our survey regarding the 2-day training you just took:
- URL: www.surveymonkey.com/r/JJQFRX7

