## **COMMERCIAL START UP CHECK LIST**

Outdoor Model #	Serial #	
Indoor Model #	Serial #	
Accessory Model #	Serial #	
System Owner	Phone #	
System Address		
Installing Contractor	Phone#	Cell#
Start Up Technician	Cell #	NATE ID #
Controls Company	Contact	Phone #
Inspect the unit for transit damage Check model number(s) to match		
Install field accessories as require		· · · · · · · · · · · · · · · · · · ·
Prior to energizing the unit inspec	ct all factory/field electrical conn	ections and tighten as needed.
Verify field wiring, including access	ssories and all multi-tap transfo	rmers for correct voltage settings.
Install drain trap(s), including sec	ondary drains and traps require	ed by local and/or national codes.
Verify belt tension, belt/pulley alig	nment and check all set screw	s for proper tightness.
Power the unit. Bump the motor compressors and motors should be		• • • • • • • • • • • • • • • • • • •
If equipped with gas heat, measu exceed ½" wc. If propane verify of		
If equipped with Simplicity board(	s), check and clear fault code h	nistory.
If third party controls are involved	, verify wiring and sequence of	operation prior to powering system
	· · · · · · · · · · · · · · · · · · ·	nstalled properly, evacuate to below /length and factory required charge.
Fill in the Start Up Information as	outlined on the opposite side of	f this sheet.
Perform all start up procedures of	utlined in the installation manua	al shipped with the unit.
Provide owner with information of	acket Explain the thermostat a	and unit aparation





## START UP INFORMATION SHEET

## **VOLTAGE READING**

Outdoor Standing/Running Voltage L1-L2/ L1-L3/ L2-L3/	
Indoor Standing/Running Voltage L1-L2/ L1-L3/_ L2-L3/	
Secondary Voltage C to G Volts* C to Y1* C to Y2**With thermostat calling	
AMPERAGE READNGS - OUTDOOR	
Compressor Rated Amps Cond Fan Rated Amps	
Comp #1 L1 L2 L3 Comp #2 L1 L2 L3_	
Comp #3 L1 L2 L3 Comp #4 L1 L2 L3_	
Cond Fan #1 Cond Fan #2 Cond Fan #3 Cond Fan #4_	
AMPERAGE READINGS – INDOOR	
Evaporator Motor: Nominal HP Rated Amps Running Amps	
Power Exhaust Motor: Nominal HP Rated Amps Running Amps	
AIRFLOW	
Design CFM Dry coil Pressure Drop Calculated CFM	
TEMPERATURE READINGS	
Ambient Temp Return Air db Temp* Supply Air db Temp*	
Return Air wb Temp* Supply Air wb Temp*	
* Measure after 15 minutes of compressor run time as near to evaporator coil as is practical	
REFRIGERATION SYSTEM	
System 1 Suction Pressure Suction Temperature Superheat	
Discharge Pressure Discharge Temperature Subcooling	
System 2 Suction Pressure Suction Temperature Superheat	
Discharge Pressure Discharge Temperature Subcooling	
SPLIT SYSTEMS	
Suction Line Size Liquid Line Size Number of Elbows	
Cond. above or below the Evap? Vert. Line length Hoz. Line length Total	
Have any other accessories been added (sight glass, strainer)	
Amount Of Refrigerant added to System1 System 2	
GAS HEAT SYSTEM	
Natural or Propane (N or P) Propane Kit Installed (Y/N) Orifice Size Used	
Incoming Gas Pressure Manifold Pressure GV1 Manifold Pressure GV2	
Temperature Rise* (at high-fire) Temperature Rise* (at low-fire) *Measure after 15 minutes of run time, with supply and return temperatures taken close to the unit	